

XSBox®MOVE Quick Start Guide

1 Insert the Battery

Skip this step if you are planning a stationary use of the device without battery.

Set the power switch to OFF and insert the battery as shown.



2 Connect 3G USB-Modem



3 Setup a LAN link

Skip this step to use the device with Wi-Fi only.

Connect the RJ-45 cable to the "Ethernet" jack of the XSBox®MOVE and the other end to a free port of your network switch or directly to your computer.



4 Connect power supply

When using the battery, it should be fully charged once for at least 3-4 hours before using the device for the first time. This ensures maximum lifetime of the Li-Ion battery cells.

Afterwards power up the XSBox®MOVE by setting the power switch to the ON position. It takes some seconds before the device is ready and you may continue configuration.



5 Establish a connection

The default Wi-Fi settings are: SSID "default", channel 11, no encryption.

Open a web browser (e.g. Internet Explorer, Firefox, Safari etc.) and type in the default IP address <http://192.168.123.254> of the XSBox®MOVE.

Note: The network adapter of your computer must be configured to retrieve its IP address via DHCP or have an IP address within the same subnet as the XSBox®MOVE.

6 Logging in


After being connected to the XSBox®MOVE, the first screen you will see is the status page where you can log into the configuration interface.



Enter the default password "admin" to the field "System Password" and click the "Login" button.

7 Running the wizard

The easiest way to configure the XSBox®MOVE is using the wizard. Select the wizard checkbox and click on enter.



On the next screen you will be shown an overview of the following configuration steps.

8 Choosing a new password

First thing suggested to be done is to change the default password "admin" to a more complex and secret one.


Type in the current password "admin" and choose a new one which must be entered twice. Afterwards click on "Next".

9 Selecting the local timezone

Try to automatically detect your timezone using the button or select one from the dropdown list manually. Click on "Next".

10 Selecting WAN type

Now you must select the appropriate method to connect to the internet. In this example, we will connect using a 3G USB modem and therefore will select "3G USB Modem". Click "Next".



11

Configuring WAN

The configuration is explained using the example of a 3G USB modem.

1. **LAN IP Address*:** In this field you can set the IP address of the **XSBox®MOVE**. In general, this setting must not be changed.
2. **APN*:** This is the URL of the access point of your internet provider. It is only necessary to enter this value if the APN is not already set in your 3G modem.
3. **PIN Code*:** If your SIM card is PIN secured, you must enter it here.
4. **Dialed Number*:** Number to dial by the modem to establish a connection. In general not necessary, otherwise often *99# or *99***1#.
5. **Account*:** Username for registration to your internet account.
6. **Password*:** Password for registration to your internet account.

| | |
|------------------|-----------------|
| ▶ LAN IP Address | 192.168.123.254 |
| ▶ APN | |
| ▶ PIN Code | 1234 |
| ▶ Dialed Number | |
| ▶ Account | |
| ▶ Password | |

* This information can normally be found in the documents coming from your internet provider.

12

Configuring Wi-Fi

If you like to use the Wi-Fi functionality of the **XSBox®MOVE**, activate the wireless network access point by selecting "Enable".

In the field "Network ID" you may give your network a unique name. "Channel" lets you select the Wi-Fi-Channel to be used. It is suggested to choose "Auto" for the automatic selection of the best channel.

| | |
|---------------------|---|
| ▶ Wireless Module | <input checked="" type="radio"/> Enable <input type="radio"/> Disable |
| ▶ Network ID (SSID) | XSBoxMOVE |
| ▶ Channel | 5 |

13

Wi-Fi encryption

Never operate Wi-Fi without having enabled encryption!

The setting "Authentication" lets you choose an encryption method. WPA2PSK is the most advanced algorithm. Avoid using WEP because its safety is known to be insufficient. Enter your secret key into the field "Preshare key".

| | |
|------------------|--------------------|
| ▶ Authentication | WPA-PSK / WPA2-PSK |
| ▶ Encryption | TKIP |
| ▶ Preshare Key | thisisasecret |

14

Completion

For finishing the wizard, press "Next" again. You will then be shown a summary of your settings. Check the checkbox for accepting the new function of the Ethernet port and click on "Apply Settings" to store the new configuration. The **XSBox®MOVE** restarts and it takes some seconds to be able to reconnect to the device.

The basic configuration has now been completed and your **XSBox®MOVE** is ready for normal usage, assumed that your settings are correct.

Try to access any website like **www.4g-systems.com**.



Don't hesitate to contact us if you have any questions:
info@4g-systems.com or Tel.: +49 (0)9005 2222 13*

* 0,49 Euro per minute from German landlines

© 4G Systems GmbH & Co. KG | Barmbeker Straße 2 | 22303 Hamburg, Germany | www.4g-systems.com

P/N_4602_000030_03