

HOYA IrWave 520UK USB-IrDA Installation Guide

System requirements:

Before you begin installing the **HOYA IrWave 520UK USB-IrDA** device, be sure your computer meets the following system requirements.

- ▶ USB port (USB Specification Version 1.1 compliant).
- ▶ CD-ROM or DVD-ROM drive (for use with the Windows CD).
- ▶ One of the following operating systems:
Microsoft® Windows 98/98SE, Windows Millennium Edition (Me) or Windows 2000.

Device driver installation:

The setup program will auto-detect which operating system do you using. Follow the instructions for your operating system : Windows 98/98SE, Windows Millennium Edition or Windows 2000.

- ***Make sure that the HOYA IR520UK Usb-IrDA device is not plugged in before installing this device driver.***

1. Double click on the **IR520UK** icon found on the CD.
2. Click **Next** when the Install Shield Wizard appears.
3. Confirm the Destination Directory and click **Next** to proceed.
4. Confirm the Target Folder and click **Next**.
5. The Add Infrared Device Wizard appears on the screen, simply click **Next**.
6. Highlight the **HOYA Computer Co.**, under manufacturer list and select the **HOYA IR520UK USB-IrDA device** under infrared devices. Choose the appropriate file which corresponds to your operating system.
7. The device drivers will now be successfully loaded and it is important to restart your computer.

- ***You can now plug in your HOYA IrWave 520UK USB-IrDA device once your system is restarted. The blinking LED on the unit indicates that the unit is working properly.***

Un-Installation for Windows 98/98SE, Windows Millennium Edition or Windows 2000:

1. Click on Add/Remove Programs from the Windows Control Panel.
 2. Select **HOYA IR520UK USB-IrDA Device** and click Remove.
 3. Go into Windows Device Manager and remove **HOYA IrWAVE 520UK USB-IrDA** and **Infrared Communication Device** under the Infrared Devices category.
 4. Select **HOYA IrWAVE 520UK USB IrDA – Windows xxx** under the Network Adapters category and click Remove.
- ***You have now successfully uninstalled your HOYA IrWave 520UK USB-IrDA device. Please un-plug the HOYA IR520UK USB-IrDA device and restart your computer to finalize the settings.***

Initiating the IR Transfer Link program:

Follow the instructions for the appropriate operating system.

◇ **Windows 98/98SE:**

1. Double click My Computer (Infrared recipient should be showing).
2. Double click Control Panel.
3. Double click Infrared.
4. Click the Options tab.
5. Select the Enable infrared communications check box.
6. Click Identification tab.
7. Enter your Computer Name (what will be seen by other infrared users around).
8. Click and .

◇ **Windows Millennium Edition:**

1. Double click My Computer.
2. Double click Control Panel.
3. Double click Wireless Link.
4. Make sure everything is selected.
5. Click and .

◇ **Windows 2000:**

1. Double click My Computer.
 2. Double click Control Panel.
 3. Double click Wireless Link icon.
 4. Select everything on file transfer and image transfer.
 5. Click and .
-