


Selecting Pickups

- 1: Bridge Pickup
(Blue LED)
- 2: Bridge and Neck Pickups
(Blue and Green LEDs)
- 3: Neck Pickup
(Green LED)



NOTE Battery is only for lighting. Output is not interrupted if battery runs out.

Adjustment of Bridge

String Action

Adjust the bridge saddle height by rotating height adjustment screws ①.

Intonation Adjustment

If the pitch at the 12th fret is sharp compared to the harmonic tone:

→ Rotate the intonation adjusting screw ② clockwise.

If the pitch at the 12th fret is flat compared to the harmonic tone:

→ Rotate the intonation adjusting screw ② counter-clockwise.

